
BARBOY Assembly Instruction



Before you get started




Recommendation: If the furniture is placed on a soft surface (wooden floor, linoleum etc.) it is recommended to keep the protective cover on the wheels to prevent scratching the floor.

Maintenance: Wipe off with a damp cloth. Grease stains can be removed with soapy water. Do not use abrasive on cloth or substances as it will scratch the painted surface. If the cassettes move too easily they can be tightening by the metal handle on the top of the Barboy (see drawing no. 3) Slight tolerance in diameter of cylinder may occur. Contact the store where you purchased your product for further details.

For indoor use only.

Box contains:



Barboy × 1


You may also need:



Hex Key Ø5


In case you need to tighten bolts. You may also need an hex key.


- 1. Tighten handle. The handle must be tightend periodically.
- 2. Wheels are delivered with plastic protectors to prevent scratches, which can be removed at your preference




Barboy has fulfilled the requirements in EN 14749:2005 Domestic and kitchen storage units and worktops. The test has been performed by the DANISH TECHNOLIGICAL INSTITUTE.

If boxes are overloaded drawers may hang. Please be aware of recommended maximum weight in the following positions. The stated maximum recommended weight is based on the state of the opposite unit(s) are empty.





When bottom drawer is empty do not fill anything in the the two top drawers or on the top plate



In case you need to tighten the bolts on the back, be extra careful when tightening to ensure you won't damage the painted surfaces of the bolts.

